

[c o r k s p o r t]



CorkSport Adjustable Rear Strut brace Mx3/Escort/Protege Installation Instructions

Tools required

- 14mm wrench
- High speed grinder
- Tin snips

Step 1: Park your car on a flat level surface and set the e-brake.

Step 2: Remove the rear package tray cover to gain access to the nuts that hold the upper strut mount to the car body. Mark the sheet metal as shown in the picture below and cut out the section.



This will allow you enough space to fit the rear strut brace bracket into the car. Bolt up the end bracket and re-install the package tray.

Step 4: Tighten down the nuts/bolts to 34-46 ft lbs or torque and you are ready to go!

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK