

[ c o r k s p o r t ]



### Installation Instructions for CorkSport Shock/Strut Tower Bar

#### Tool required (Most vehicles)

- 14mm wrench
- Torque Wrench with 14mm socket

Step 1: Park your car on a flat level surface and set the e-brake.

Step 2: Locate the upper strut/shock mounts. For the front bar this will be under the hood. The rear bar will be located in the trunk or hatch behind the passenger seats. On a rear tower brace/bar you may have to remove trunk/hatch panels to gain access to the upper mounts. This will also require trimming/cutting of the interior plastic/trunk liner for proper fitment. This will require additional tools. The upper mount for a 99-03 protégé is shown below



Step 3: Remove the nuts/bolts from the upper strut/shock mount.

Step 4: Place the CorkSport strut bar onto the studs that protrude through the strut/shock towers. For vehicle with bolts instead of nuts set the bar so the bolt can be re-installed into all the holes.

Step 5: Tighten down the nuts/bolts to 34-46 ft lbs or torque and you are ready to go!

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK