

[c o r k s p o r t]



CorkSport 90-94 Protégé Rear Deck Lid Panel Install Instructions.

Tools Required

- 10mm Socket (deep well)
- 1/4 or 3/8 Drive Ratchet
- Phillips Head Screw Driver

Contents

- 1 CorkSport Deck Lid Panel
- 8 M6 Flange Style Nuts
- 5 Page Install Instructions

NOTE: If you plan to paint this part, it is recommended that you test fit prior to painting.

Step 1: Park Protégé on smooth level surface and open trunk lid.

Step 2: Locate the 8 10mm head nuts and remove.

Pictures are located on next page.

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

Step 3: Locate 3 phillips head screws and remove. Remove panel

Note: If your Protégé still has the stock deck lid panel with license plate light, unplug lights.



Step 4: Make sure all gasket material is removed from deck lid. Remove the 3 plastic clips from the deck lid.

Note: The clips can just be twisted clockwise and will remove.



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

Step 5: Line up studs on bottom of new deck lid panel with holes in deck lid and install using the supplied 8 M6 flange style nuts.

Caution: You only need to torque the nuts to 8-12 ft/lbs. If you over tighten these nuts you may break the fiberglass.

Note: Apply silicone sealant to holes in deck lid prior to installation to help prevent leaks.



Pictures continued on next page.

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK



This completes the installation of the CorkSport rear deck lid panel.
Enjoy.



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK