

[c o r k s p o r t]



Installation Instructions for CS Radiator Panel for FC Rx7

Tools Required

- Sandpaper or File
- 10mm socket wrench
- 8mm socket
- Flat head screw driver, small
- Drill or Dremel

Contents

- Radiator Panel
- Bond Washer, QTY=6
- 2 Page Install Instructions
- Bolt, QTY=4
- Screw, Self Tapping, QTY=2

1990 Rx7 GXL was used for creation of installation instructions. Installation will take 30-60 minutes for most installers.

Note: Radiator compartment will vary from Rx7 to Rx7 depending on year and options. Installation in your Rx7 may vary slightly from instructions below.

- 1.0 Remove coolant overflow bottle, two (2) 10mm bolts.
- 2.0 Remove upper radiator shrouds, twelve (12) push pins. Left side has seven (7) plastic push pins. Right side has five (5) plastic push pins.




Thank you for your purchase. If you have any questions please call CorkSport at 360 260 CORK

- 3.0 Remove air box inlet tube, two (2) 10mm bolts and one (1) 10mm screw.
- 4.0 Test fit radiator panel, some adjustments will be required on most cars for good fitment.
 - 4.1 Four (4) 6mm holes should line up with bolts removed in step 1 and 3. Slightly enlarge holes with drill/Dremel if necessary. Seat 10mm bolts but do not tighten.
 - 4.2 Some trimming/sanding/filing of other openings may be required.
 - 4.2.1 1/8" clearance around hood latch is desired.
 - 4.2.2 1/8" clearance around hood release lever is desired. Make sure lever can easily be used.
 - 4.2.3 At least 1/4" clearance between headlight shroud is desired.
 - 4.2.4 1/8" clearance around rubber hood stops is desired.
 - 4.3 Remove radiator panel once desired fitment is obtained.
 - 4.4 Paint panel, if desired.

Note: AC accumulator may not line up with opening. Some adjustment can be made to accumulator position but some cars will not align well.

- 5.0 Set coolant overflow container in place with cap secured.
- 6.0 Put radiator panel in place. Panel should sit flush once coolant container is in position.
- 7.0 Install two (2) of the 10mm bolts and washers provided. Do not over tighten or you will crack fiberglass!
- 8.0 Put air box inlet tube in position. Installation is reverse of removal.
- 9.0 Install self-tapping screw with washer in driver-side front corner and passenger side back corner. This is optional but if you use screws make sure you are centered on sheet metal.



Thank you for your purchase. If you have any questions please call CorkSport at 360 260 CORK