

CorkSport

MAZDA PERFORMANCE



Installation Instructions for CorkSport 2006-2008 Mazda6 Type 'KS' Lip

Tools required

- Sand Paper 80 grit
- Philips Screw Driver
- Floor Jack
- Two Jack Stands
- Blue Painters Tape.
- Sharpie

Contents

- Type 'KS' Lip
- Four Small Self tapping screws
- Two Large Self tapping screws
- Four 6 inch long sections of 3M double sided tape
- Two 25mm large washers with small hole
- Four 10mm small washers
- Two 22mm large washers with large hole
- Two black vinyl decals
- Four page installation instructions
- 10mm small washers



CorkSport recommends this lip be installed by a professional auto body shop that has experience in aftermarket components. If you wish to install the lip yourself we have included this set of instructions to help the Do-It-Yourselfer install the CorkSport Type 'KS' lip. Proceed at your own risk.

CAUTION: Installation of the lip will make the front of your car lower and sit further forward. Take care when entering steep driveways or pulling up to curbs so as not to hit your lip and damage it.

TIP: CorkSport recommends that you test fit the lip before installation and painting to make sure the contours of the lip fit the bumper evenly. We recommend putting blue painters tape against the bumper when doing the initial test fit to keep from scratching the paint on your bumper.

DANGER: Follow instructions that came with your jack/stands. Death and or significant property damage could result if you do not.

Step 1: Jack up front of vehicle and place securely on jack stands. For ease of installation, remove front wheels/tires.

Step 2: Place the lip on one edge of wheel well (a second person will be helpful for this) then move the lip up to the bottom of bumper until you can place the other side of the lip onto the other wheel well edge.



Step 3: (Optional) Note where the bumper is visible through the left and right lip opening. Make a mark on the bumper with the sharpie to show the opening dimensions.



Step 4: (Optional) Place one black vinyl piece on your bumper over the marks you have made with the sharpie. Looking at the front of the car the bumper should be covered by the black vinyl when viewed through the lip from the front of the car.



Step 5: Attach the four 6 inch long section of 3m tape to the locations of the lip shown below. Attach the tape to the inside edge of the lip where it meets the bumper. This step needs to be done before mounting the screws to hold the lip to the car. The 3m tape is provided to help the lip sit against the bumper contours. It is not intended to secure the lip to your bumper.



Step 6: Place the four supplied small self-tapping screws (two per side) and 10mm washers through the pre- drilled holes on edge of lip into the edge of wheel well.



Step 7: Install the two supplied large self-tapping screws and large 25mm washers with the small hole through holes in bottom of lip to bumper. Use the two large 22mm washers with the large hole as spacers between lip and bumper if there is a gap.



Step 8: Make sure the 3m tape is secure against the car bumper by pressing firmly along the edges where the 3m tape is applied. Remember the 3m tape is provided to help the lip sit against the bumper contours. It is not intended to secure the lip to your bumper. The mounting screws are provided to keep the lip on your car.

Step 9: If wheels/tires were removed, replace them. Remove vehicle from jack stands.