

CorkSport Mazda and Mazdaspeed Radiator Cap

For all makes and models except Mazda 3 and Mazdaspeed 3, Mazda 5 and CX7



Pre-Installation Notes:



Warning: Turn off your engine and allow the vehicle to cool for at least 30 minutes. Engine coolant can reach temperatures of 200° Fahrenheit or higher.



These instructions were written for reference only and the use of a factory service manual is recommended. Please read these instructions thoroughly prior to starting installation



When working on your car, you should always wear mechanics gloves or other form of hand protection as well as ANSI approved safety glasses.

Materials and Time:



General Info.

Part #: Gen-6-013

Time Est: 5 min



Tooling List

None Required



Parts List

One(1) CorkSport Radiator Cap

Installation Instructions:

1. **Park vehicle on a level surface and let it cool.** Let the engine fully cool before starting the install. The engine and surrounding engine components can be very hot. **Use extreme caution!**
2. **Remove the Stock Radiator Cap.**
 - A. Open the hood and locate the radiator and radiator cap.
 - B. Remove the old cap.
3. **Install the CorkSport Radiator Cap**
 - A. Replace the cap with the new one and turn it clockwise, getting it as tight as you can.
 - B. Start engine, fully warm up car, and keep the hood popped. Keep at a safe distance from the radiator and inspect the cap for discharge or bubbling around the edges.



What's Next? CorkSport Mazda LED Light Kit – Enhance the look of your interior lights with CorkSport's LED light kit that replaces the incandescent bulbs for the interior lights in your Mazda. Available for the Mazda Protégé, 2003-2008 Mazda 6, 2006-2007 Mazdaspeed 6, and the 2004-2008 RX8.