

CorkSport Mazdaspeed 6 Rear Sway Bar

2006-2007 Mazdaspeed 6



The CorkSport Rear Sway Bar is a great addition to improving the handling performance to the Mazdaspeed 6. It will minimize traction robbing body lean that rolls the outside tires off the pavement by attaching both sides of the rear suspension together, increasing spring rate and fine tune the handling of your speed 6. It is 70% stiffer than the stock bar for dramatically improved cornering potential and a distinct track and autocross advantage over stock. We hope you enjoy the improved handling of your Mazdaspeed 6. Please let us know your feedback by submitting a review at:

<http://www.corksport.com/corksport-mazdaspeed-6-rear-swaybar.html>

Pre-Installation Notes:



Make sure your vehicle is completely cooled down prior to starting installation. You will have to remove part of your exhaust to give better access during the installation.



These instructions were written for reference only and the use of a factory service manual is recommended. Please read these instructions thoroughly prior to starting installation



How our instructions work: To best cover all of our customers experience levels, we have included an overview checklist for the more technically advanced users along with step-by-step instructions for customers that require additional detail.



These installation instructions are for use with a 2006-2007 MS6. The torque values for this installation range from 30-85ft-lbs.

Materials and Time:



General Info.

Part #: Ate-3-070

Time Est: 3-4 Hours

Wrench Rating: 4/5



Tooling List

3/8" Drive Ratchet
24" Extension
3/8" Swivel
14mm Socket
17mm Socket
17mm Open End Wrench
Screwdriver
Mallet
Jack
Jack Stands (preferably a lift)
Grease
Torque Wrench



Parts List

CorkSport MS6 Rear Sway Bar
Energy Suspension Sway Bar Bushing Kit

Need Help With Your Installation?

Call (360) 260-CORK

Checklist

This is an overview of each step in the build. You can use this as a reference and a checklist as you button up the work on your car

1. Remove the Factory Rear Sway Bar

- 1a) Jack up rear of vehicle** and place on jack stands. Remove the rear wheels.
- 1b) Remove the exhaust center section** between the mufflers (2 nuts per muffler) and catalytic converter (two bolts) using a 14mm socket.
- 1c) Unbolt driveshaft by loosening four (4) bolts** from the nut side with a 14mm socket. Push out bolts. (See [Figure 1a](#))
- 1d) Unbolt the front differential mount** by supporting the front of the rear differential with a jack. Remove the two (2) bolts using a 17mm open ended wrench (bolts shown in [Figure 1b](#)). Carefully lower the front of the differential and the driveshaft.
- 1e) Undo the electrical connections** running to rear differential (shown in [Figure 1d](#)) and detach them from the sub frame.
- 1f) Unbolt the driver side rear differential mount** by supporting the rear of the differential with a jack. Using a 24" long extension, swivel, and 17mm socket, unbolt the driver's side rear differential mount (bolt shown in [Figure 1e](#) and tool placement shown in [Figure 1f](#)). Lower the rear of the differential carefully.
- 1g) Unbolt the end link from the control arm** using a 14mm socket. (See [Figure 1g](#)). Repeat for the other side.
- 1h) Unbolt the control arm** by supporting it with a jack and unbolting it from the upright/hub using a 17mm socket (bolt shown in [Figure 1h](#)). Lower the control arm slowly. Remove the spring from the car. Repeat for other side.
- 1i) Unbolt the sway bar brackets** using a 14mm socket and remove them. (See [Figure 1i](#))
- 1j) Remove the rear sway bar** by pulling the differential down as far as possible and slide the rear sway bar towards the front of the car over the rear differential. The casting (shown in [Figure 1j](#)) may need to be filed down.

Checklist

This is an overview of each step in the build. You can use this as a reference and a checklist as you button up the work on your car

2. Install the CorkSport Rear Sway Bar

- 2a) **Swap the end links** from the stock bar to the CorkSport Rear Sway Bar using a 14mm socket. Torque the end links to 30-45ft-lbs. Grease the supplied bushings and install onto bar.
- 2b) **Install the CorkSport Rear Sway Bar** by sliding it over the differential towards the rear of the car. Position rear sway bar in approximate position and insert end links into control arms but do not attach yet.
- 2c) **Reinstall springs and control arms.** Jack up control arms until lined up with the upright. Reattach the control arm to the upright using a 17mm socket. Torque to 55-75ft-lbs.
- 2d) **Reattach the rear differential mount** by jacking up the back of differential and reinstalling the bolt using 24" extension, a swivel, and a 17mm socket. Torque to 32-45ft-lbs.
- 2e) **Reattach the front differential mount** by jacking up the front of the rear differential while lining up the driveshaft. Install the bolts using a 17mm open ended wrench. Torque to 55-78ft-lbs.
- 2f) **Reattach driveshaft by inserting bolts** from the back and tightening down nuts with 14mm socket. Torque to 35-43ft-lbs.
- 2g) **Reattach the electrical connections** to the sub frame and reconnect connections.
- 2h) **Position the end links and reattach to the control arms.** Torque to 30-45ft-lbs.
- 2i) **Mount the sway bar to the chassis** with a 14mm socket using the supplied brackets and washers and reusing the stock nuts (shown in **Figure 2a**). Torque to 30-45ft-lbs. To clear the drivers side axle boot, the grease fitting may have to be unscrewed from the mount (see **Figure 2b**).
- 2j) **Remount your wheels and lower the vehicle.** Torque the lug nuts to 80-85ft-lbs.



This completes the installation of the CorkSport Rear Sway Bar. Start your car and go for a brisk drive. Try to put some loading on the car in the corners to ensure all suspension components are functioning properly. If you hear any noises or creaks, double check all hardware and make sure the sway bar bushings are properly greased.

Detailed Instructions



These instructions are made for the 06-07 Mazdaspeed 6.

1. Remove the Factory Rear Sway Bar

- A) Jack up the rear of the vehicle and place on jack stands. Remove the rear wheels.
- B) Remove the exhaust center section between the mufflers (two (2) nuts per muffler) and catalytic converter (two (2) bolts), using a 14mm socket. Some pictures will show it still installed but it is best to remove it.
- C) **Unbolt the drive shaft by removing the four (4) 14mm nuts** from the end of the driveshaft (3 of them circled in red in **Figure 1a**, the fourth bolt is behind the driveshaft). Push the bolts out through the back. The driveshaft will stay in place until the differential is lowered.
- D) **Unbolt the front differential mount** by supporting the front of the rear differential with a jack. Remove the two (2) bolts (shown in **Figure 1b**) using a 17mm open ended wrench. Lower the differential slowly while holding the driveshaft to ensure it doesn't fall out. Remove the jack and let the differential and driveshaft hang free (see **Figure 1c**).
- E) **Undo the two electrical connections** going to the rear differential (the front connection is shown in **Figure 1d** and the second connection is just behind it). Unclip them from the sub frame. Each wire loom is held to the subframe by two clips.



Figure 1a



Figure 1b



Figure 1c



Figure 1d

Need Help With Your Installation?

Call (360) 260-CORK

1. Remove the Factory Rear Sway Bar (continued)

F) Remove the driver side rear differential mount by supporting the back of the rear differential with the jack. Using a 24" extension, swivel, and 17mm socket, unbolt the driver side rear differential mount. It is most easily accessed from between the differential and the sub frame (Bolt shown in [Figure 1e](#), and tool access shown in [Figure 1f](#)). Lower the differential and remove the jack. The differential is still supported by the passenger side rear mount so it will stay in place.




Figure 1e

G) Unbolt the end links from the control arm using a 14mm socket (shown in [Figure 1g](#)). Repeat for the other side.

H) Unbolt the rear control arm by supporting the control arm using the jack. Unbolt the control arm from the upright/hub using a 17mm socket (bolt shown in [Figure 1h](#)). Slowly lower the control arm making sure the spring doesn't fly out. Once lowered remove the spring from the car. Repeat for the other side of the vehicle.



Figure 1f

I) Unbolt the rear sway bar mounts by removing the four (4) nuts using a 14mm socket. The two (2) bolts holding on one (1) mount shown in [Figure 1i](#). Remove the mounts from the bar.



Figure 1h




Figure 1g



Figure 1i

1. Remove the Factory Rear Sway Bar (continued)

- J) **Remove the sway bar by sliding it towards the front of the vehicle** over the rear differential. This can be difficult and the casting on the differential (shown in **Figure 1j**) may have to be filed down to gain extra clearance. It also makes it slightly easier if you can get the arms of the sway bar underneath the control arms.



Figure 1j

2. Install the CorkSport Rear Sway Bar

- A) **Swap the end links from the stock bar** onto the CorkSport Rear Sway Bar using a 14mm socket. Torque to 30-45ft-lbs. Grease the supplied bushing and install onto the bar in approximately the same location as where the stock bushings are on the stock bar.
- B) **Slide the CorkSport Rear Sway Bar** over the differential towards the rear of the vehicle. Position the bar into place and insert the end links into the slots in the control arms but do not mount yet.
- C) **Reinstall the rear springs and control arms** by jacking up the control arm until it is lined up with the upright/hub. Make sure that the springs are fully seated against the rubber stops in the control arm. Reattach the control arm using a 17mm socket. You may have to use a mallet to tap the upright/hub in place. It also works to use a screw driver inserted into the hole to help line the holes up. Be careful to not get the screwdriver stuck though. Torque the bolt to 55-75ft-lbs.
- D) **Reattach the driver side rear differential mount by jacking up the back of differential** and reinstalling the bolt using 24" extension, a swivel, and a 17mm socket. Torque the bolt to 32-45ft-lbs. It may be necessary to slide the differential towards the back of the car to get it to line up correctly with the mount. This step may be easier with two people, but can be done with one. To get the bolt started you can hand thread it in by reaching from behind the subframe, however it is a tight area.
- E) **Reattach the front differential mount** by jacking up the front of the rear differential while also lining up driveshaft. Reinstall the two (2) bolts using 17mm open ended wrench. Torque the bolts to 55-78ft-lbs. It is necessary to line up the driveshaft while jacking the differential up in place, otherwise the driveshaft will not slide back into position if the differential is already mounted in place.
- F) **Reattach the driveshaft by inserting the bolts** from the back. The heads of the bolts rest against the differential output to resist spinning. Tighten down nuts with 14mm socket and torque to 35-43ft-lbs.
- G) **Reattach the electrical connections** to the sub frame and reconnect connections.
- H) **Position the end links and reattach to the control arms using a 14mm socket.** A small screw driver can come in handy to help realign the holes. Torque to 30-45ft-lbs.

2. Install the CorkSport Rear Sway Bar (continued)

- H) Using the supplied brackets mount the sway bar to the chassis reusing the stock nuts and the supplied washers (Figure 2a) using a 14mm socket. Torque to 30-45ft-lbs. To clear the drivers side axle boot, the grease fitting may have to be unscrewed from the driver side mount (shown in Figure 2b).
- I) Remount your rear wheels and lower the vehicle. Torque the lug nuts to 80-85ft-lbs.




Figure 2a



Figure 2b

- ! This completes the installation of the CorkSport Rear Sway Bar. Start your car and go for a brisk drive. Try to put some loading on the car in the corners to ensure all suspension components are functioning properly. If you hear any noises or creaks, double check all hardware and make sure the sway bar bushings are properly greased.

What's Next:

CorkSport Front Strut Bar for Mazdaspeed 6



Adding a front strut bar to your Mazdaspeed 6, you will increase the chassis stiffness and create additional traction allowing you to more easily accelerate out of a turn
<http://www.corksport.com/corksport-front-strut-bar-for-mazdaspeed-6.html>